INSTRUCTIONS FOR SERVICE BULLETIN 1/03

- 1) Follow with the finger all eyelets in the union of the load tape wires in the mouth of the envelope.
- 2) In case of noticing any irregularity (like small saw dents or a sharp edge that can cut) pass a small file or a small smoother machina like Dremel (see photo 1), polosh the edge until is smooth. Watch carefully not to damage the wire nor the load tape, mainly protecting the loadtape with a small leather or thick fabric like cordura(see photo 2).
- 3) In case there is any damaged tape in more than 1 mm, it will be repaired as usual: Without removing the damaged load tape, it will be overpassed another tape of the same characteristics by 1,5 m on each side and Hill be sewn according to the Flight and Maintenance Manual.



Signed Josep M Llado Costa Ing. Aeronáutico