

'KUBÍČEK' BASKET AND BURNERS WITH ULTRAMAGIC EQUIPMENT

The technical content of this document is approved under the authority of the DOA, ref.: EASA.21J.351.

4.1 GENERAL INFORMATION

The information contained here in this document, supplements or supersedes the basic manual only in the areas listed. For limitations, procedures and performance information not contained in this supplement, consult the basic Ultramagic Flight Manual.

This supplement is issued to cover additional actions to be taken to safely and efficiently use Kubíček baskets and burners with Ultramagic envelopes.

4.2 LIMITATIONS

4.2.15 Other manufacturers equipment

The burners and baskets manufactured by Kubíček which may be used in combination with Ultramagic envelopes are listed in section 4.8

The equipment must be identifiable as an FAA type certified vehicle with the applicable Type Certificate Data Sheet B04CE.

CAUTION: Kubicek burners extinguishing due to lack of oxygen was proved at levels higher than 23000 ft ALT.

4.3 EMERGENCY PROCEDURES

No change

4.4 NORMAL PROCEDURES

4.4.5.2 Rigging the basket and burner

Kubíček burner frames are similar to Ultramagic with a single plate corner lug. Assembly is therefore similar to that of an Ultramagic and the same checks should be carried out.

4.4.10 Control during flight

Add to 4.10.2 Fuel management as follows:

SUPPLEMENT 4 US, Issue 8 HOT AIR BALLOON FLIGHT MANUAL



B 0 T T 0

> E N D S

page 2 of 3

v

Note: Burner – run only one cylinder down so that there are two cylinders of minimum 20% fuel capacity for landing, flame check.

4.5 LOADING

No change

4.6 BALLOON AND SYSTEM DESCRIPTION

4.6.2.2 Burner and burner frame

Refer to applicable Kubíček Flight Manual approved for use in the USA as listed on TCDS B04CE.

4.6.2.3 Basket

Refer to applicable Kubíček Flight Manual approved for use in the USA as listed on TCDS B04CE.

4.6.2.4 Fuel Cylinders

Refer to applicable Kubíček Flight Manual approved for use in the USA as listed on TCDS B04CE.

4.7 BALLOON MAINTENANCE, HANDLING AND CARE

Refer to applicable Kubicek Maintenance Manual approved for use in the USA as listed on TCDS B04CE.

4.8 OTHER MANUFACTURERS EQUIPMENT

4.8.3 Other Equipment

KUBÍČEK BASKETS						
Basket Size (cm) Width ±5 cm	Туре	Empty Mass (kg)	UM Envelope size range			
85 x (100 - 116) 116 x (116 - 126) 116 x (116 - 126) 116x125/100x120 116 x (125 - 135) 116 x (140 - 150) 116 x (140 - 150) 116 x (155 - 180) 116 x 155 125 x (179 - 183) 125 x (208 - 226) 166 x 300	K10(open) K12(open) K12a(open) K13/K13S (open) K15(open) K16(open) K17(open) K18(open) K19 (open) K22(open) K25P(single partition) K40Y (Y partition)	60 80 80 80 / 55 85 90 90 100 95 105 140 250	56 - 77 65 - 90 65 - 90 65 - 120 65 - 105 90 - 130 90 - 130 90 - 150 90 - 150 130 - 250 180 - 250			

SUPPLEMENT 4 US, Issue 8 HOT AIR BALLOON FLIGHT MANUAL

160 x 240	K32T (T partition)	210	180 - 250
160 x 250	K32TT (TT partition)	210	180 - 250
160 x 300	K50TT (TT partition)	300	180 - 250
160 x 380/390	K60/K60X	350/378	250 - 425
160 x 440	K70	400	250 - 425
160 x 610	K100	550	355 - 500
160 x 480	K80	450	300 - 500



KUBÍČEK BURNERS and CYLINDERS					
Burner Type	Mass (kg)	UM Envelope size range			
Ignis Double (K10 to K25P) Ignis Triple (K25P to K50TT) Ignis Quad (K40Y to K100) Sirius Single (K10 to K19)	23 to 43 41 to 59 56 to 102 18	65 - 210 ¹ 145 - 300 ² 210 - 500 30 - 120			

¹ Not exceeding a MTOM of 1,940kg

² Ignis with s/n below 516 can only be used up to a 250

Cylinder Type	Empty Mass (kg)	Fuel Capacity (kg)	UM Envelope size range
VA-50 VA-70 KB72L KB85L KB97L	15 18 20 22 24	21 30 31 / 34* 36 / 40* 41 / 46*	AII AII AII AII

^{*} When using LPG

See General Notes below

Notes:

- Dimensions of the basket are external in the base.
- UM envelope sizes are given in thousands of cubic feet, so 65 mean 65.000 ft³.